

Ag Leader Edge



Photo courtesy of Ag Leader Technology

- Pre-Harvest Checklist: <http://www.agleader.com/docs/insights-julo9-checklist.pdf>.
- Quick Reference Sheet: <http://dealer.agleader.com/kbp/index.php?View=afile&CategoryID=437&EntryID=762>.
- Current Firmware (9/16/2011): Version 4.5.0. You can download this firmware from: <http://dealer.agleader.com/kbp/index.php?CategoryID=98>.
- Additional Information :
 - The Edge has an internal memory. You have to copy the log files (ilf extension) to the card manually or turn on the automatic option. After copying, files are flagged and deleted from internal memory after 30 days so make sure the files on the card get backed up to your computer.
 - Get in the habit of creating monitor backups. This is especially helpful if your touch screen goes bad or you experience other monitor issues during harvest.
 - To avoid data loss, backup the ilf files to a folder on your computer before reading into any mapping software. You should also check to make sure data is recording correctly early in the harvest season using your mapping software.
- For more information log on to <http://dealer.agleader.com/kbp/> or contact Ag Leader technical support at (515) 232-5363.